



Tough Stuff Products, Inc.

Windshield Brackets

READ ALL OF THE INSTRUCTIONS BEFORE STARTING!

Check our website for any updated instructions! www.toughstuffproducts.com >>
[Jeep® Accessories](#)>>[Windshield Brackets](#)>>[Installation Instructions](#)

Tools Required

Drill	3/16 & 5/16 inch drill bits
Hand Tools	Dull kitchen knife

Instructions

Remove hardtop or fold back soft top to access top corners of windshield.

Using the dull knife, carefully peel off the thick rubber gasket on top of the windshield, approx. 4 inches inward on each side.

Carefully pull the rubber off of the plastic retaining pin and tape the gasket back as pictured.

Hold the bracket in place; note how the top mounting surface will sit flat when properly placed. Hold bracket in place and use the 3/16 inch drill bit to drill through the lowermost hole (into the door frame).

Remove the bracket, use the 5/16 inch drill bit to enlarge the hole you just drilled.

Insert a rubber Wellnut into the hole and bolt the bracket in place.

Next, drill through the topmost hole into the top of the windshield frame. Remove bracket. Repeat above steps to install Wellnut into topmost hole. Bolt bracket into place with BOTH top and bottom bolts and Wellnuts.

Drill 3/16 inch hole into CENTER hole in bracket. Remove and repeat.

Remove duct tape and carefully stretch rubber gasket back over plastic retaining pin.

Re-adhere the gasket back into original location. If it does not stick well, you may have to use a weather strip adhesive (available at any Auto parts store) to glue the gasket in place.

A black nylon tie is also included to attach your radio antenna to the passenger side bracket. Leave the tie loose, so the antenna will not directly touch the metal bracket.



Thank you for purchasing our product, we also manufacture many other body protection and accessory items for your vehicle, our complete product line can be viewed at www.toughstuffproducts.com.